


instruction for force adjustment




position 9 = soft (clockwise direction)
position 1 = firm (counter- clockwise direction)

During the adjustment you will hear a positive "click" at each position of the adjustment.

Instruction for the front axle B16

The adjusting element of the front struts is located at the bottom edge of the strut, covered by a blue plastic cap. That cap must be removed before adjusting. After the adjustment the cap must be replaced again.

list of torques	- list						
Thread	M 16	M 14	M 12	M 10	M8		
Torque Nm	110	72	45	25	13		
Torque ft lb	83	54	34	19	10		



Do not use impact tools for loosening or tightening fasteners, because this may destroy the threads. Self- locking nuts must only be used once!



Before installation please observe the following points:

- Read all information in this manual carefully.

 All suspention components are fitted and removed acc. to the manufacturer's specifications for fitting and removing, if not otherwise required in these instructions.
 - Check that your vehicle type is listed in the certificate as being released for this kit.
- Check the product for all components before starting installation!
- Check that dimensions and fastening points are comparable between the original and Bilstein shock absorbers.
 - Remove the negative battery pole.
- Directional references (left, right, front, rear) are always with reference to the driving direction.
 - The test vehicles are left- hand drive cars.

After installation please observe the following points:

- Set the vehicle height by adjusting spring plates and lock nuts on the new dampers. Only use the supplied spanner wrenches.
 - After installing the suspension system, caster and camber must be checked and adjusted according to manufacturer's specifications.

 Check and reset load- dependent brake compensator and ABS system according to manufacturer's specifications.
 - Check and adjust headlight aim. -
 - Because the vehicle has been lowered, freedom of movement for all wheel-/tire-combinations must be checked.
- All rubber- mounted strut/ damper attachments must not be fully tightened until AFTER the suspension system is loaded (wheels on the ground). Other mounting fasteners (for example brackets) must be securely tightened BEFORE load is placed on the suspension system.
 - Connect the negative battery pole.

All diagrams are generalized and not to scale! brackets, etc. specific to strut are not shown!



mounting instruction for front and rear axle

Removal

Place vehicle on a chassis hoist, lift it and remove wheels.



The lower control arm must be supported by suitable means!

Remove bottom mount.

Remove top fixing nut from support bearing.

Do not remove centre nut at this time!

Remove complete strut and clamp it in an appropriate strut vice.

Using a suitable spring compressor, compress suspension spring until tension on support bearing is released.

Release centre nut and remove original mounting parts and coil spring. Please refer to diagram to identify which parts will be replaced with BILSTEIN- supplied components.

Install

Assemble BILSTEIN and/ or original mounting parts, as well as the new BILSTEIN spring on the BILSTEIN strut in reverse sequence of removal.

Note for BMW E39 M5 rear:

Original spring pad must be replaced by Original part no. 33.53-1091 924 (see. Figure)!



IMPORTANT! Spring plates must not be adjusted outside the ranges specified below!

The correct mounting position of the suspension springs can be determined by the printing on the springs; install them with the print upright.

Do not reuse original- bumper, since BILSTEIN- strut has built in bump stop.

Fit assembled BILSTEIN strut to the vehicle in reverse sequence to removal.



