


Supporting Today's Vehicle Technician

Inspect Distributor Cam Gear Before Installing Distributor

Application	All gear driven distributors
Problem	Original distributor has abnormal gear wear or breakage.
Cause	Distributor gear and camshaft drive gear wear together in a pattern. When only one of the pair is replaced, the likelihood of a repeat failure is very high.
Solution	Inspect both camshaft drive gear and distributor gear for wear. If either is worn, both must be replaced.
	Inspect oil pump. If pump does not turn freely, it must be replaced.
Important Note	When replacing the distributor, it is extremely important to match the replacement unit to the original. Key points of comparison are

the replacement unit to the original. Key points of comparison are shown below.



For other ProTech publications, visit www.cardone.com