


# E4-WM5-Y199A00

## MOUNTING INSTRUCTION



### list of torques

	M8	M 10	M 12	M 14	M 16	Thread
	13	25	45	72	110	Torque Nm
	10	19	34	54	83	Torque ft lb



1. BILSTEIN shock absorber with original spring
2. BILSTEIN shock absorber with BILSTEIN spring
3. Original shock absorber with BILSTEIN spring

DO NOT USE IMPACT TOOLS FOR LOOSENING OR TIGHTENING FASTENERS, BECAUSE THIS MAY DESTROY THE THREADS. SELF- LOCKING NUTS MUST ONLY BE USED ONCE!

### Remove

Place vehicle on a chassis hoist, lift it, remove wheels and wheelhouse liner.



***The lower control arm must be supported by suitable means!***

Remove top and bottom fixing mount from support bearing.

Remove shock absorber and original mounting parts.

All rubber- mounted strut/ damper attachments must not be fully tightened until AFTER the suspension system is loaded ( wheels on the ground). Other mounting fasteners ( for example brackets) must be securely tightened BEFORE load is placed on the suspension system.

### Install

Fit BILSTEIN and/ or original mounting parts in BILSTEIN shock absorber in reverse sequence of removal.

If there is no dust cover delivered by BILSTEIN, the original one is to be reused.

Fit BILSTEIN shock absorber to the vehicle in reverse sequence of removal.

# E4-WM5-Y199A00 MOUNTING INSTRUCTION



ALL DIAGRAMS ARE GENERALIZED  
AND NOT TO SCALE!  
BRACKETS, ETC. SPECIFIC TO STRUT ARE NOT SHOWN!

