



**NOTE: READ INSTRUCTIONS THOROUGHLY BEFORE INSTALLATION WORK BEGINS**

Thank you for purchasing a new **DORMAN** power steering pulley! Please take note of the following installation notes to ensure proper installation.

- This pulley is a press fit pulley. Special tools and installation techniques are required to properly install this pulley. Failure to use the appropriate tools and procedures may result in damage to the pulley and/or power steering pump or an inability to fully install the new pulley on the pump shaft.
- The small bolt/nut/washer kit included with many remanufactured power steering pumps is often inadequate to install a new pulley due to the tight press fit of new parts. In this case, a quality power steering installation tool will be required.
- The outside diameter of the new pulley may be slightly different than the pulley you are replacing. This will not affect the operation of the pulley or power steering pump; however some applications may require a slightly longer belt.

**Disclaimer:**

Even though every attempt is made to ensure this information is complete and accurate, it is impossible to account for all possible circumstances or situations. Please consult with a qualified auto technician before attempting to perform any work you are not qualified to do. Automobiles can be hazardous to work on; be sure to take all necessary safety precautions. Failure to do so may result in property damage or personal injury. Certain motor vehicle standards and performance requirements may apply to your motor vehicle (such as Federal Motor Vehicle Safety Standards by the National Highway Traffic Safety Administration). Be sure that your work is performed in accordance with such standards and that you do not disable any motor vehicle safety feature.