



ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

Chevrolet 2014–07, GMC 2014–07

Please follow the proceeding steps once the Dorman Transfer Case Control Module is installed:

NOTE: The Range Actuator Learn Procedure is performed with the ignition in the Accessory Position.

1. Ignition OFF for at least 30 seconds.
2. Engage parking brake.
3. Place the transmission in Neutral.
4. Turn the S77 Transfer Case Shift Control Switch to the 2WD High position for at least 5 seconds. The 2WD High indicator may not illuminate.
5. Turn the S77 Transfer Case Shift Control Switch clockwise past the 4WD Low position to the neutral request position and hold for at least 30 seconds.
6. An audible noise from the A16 Transfer Case Motor should occur, indicating a successful learn procedure.